



Parts Included

- 1 Dino Hunter Goggles
- 1 Invisible Ink Pen
- 1 Dinosaur Tracks Stencil
- 3 Dinosaur Profile Cards


Battery Installation

- 1. Using a Phillips head screwdriver, remove the battery cover.
- 2. Insert 3 "AAA" batteries as indicated in the battery compartment.
- 3. Replace the battery cover. Do not over-tighten the screw.

CREATING YOUR NIGHTTIME ADVENTURE

Night Vision

As nighttime draws near, you can use night vision to explore while keeping your hands free. Follow trails, look for critters, and see what else you can discover.



UV Vision


Create your own dinosaur adventure using rays of ultraviolet, purple light to find dinosaur tracks in the dark and even uncover secret messages!

1 Plan Your Path:

Determine what dinosaur tracks you want to use, and the location for your dinosaur track path. The included stencil has tracks for a T-rex, Velociraptor, and Triceratops. Or, create your own animal track cut-outs for any animal you want to use in your adventure.

2 Create Your Tracks:

To set the dinosaur tracks, hold the track stencil in place and color in each track using the invisible ink pen*. For best results, apply to surfaces that are smooth, flat and porous. Place dinosaur tracks on tree trunks, leaves, stones and rocks, fences, fallen branches, cardboard, paper, or even your bedroom door! Place tracks one in front of the other just like a real dinosaur would do.




* **Note:** Remember to ask your parents for permission to write the invisible ink on different surfaces. The invisible ink will wash off with water.

Battery Safety Information

- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Different types of batteries or new and used batteries are not to be mixed.
- · Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.
- · Do not mix old and new batteries.
- · Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- · Do not dispose of batteries in fire. Battery may explode or leak.

IMPORTANT: In an environment with electrostatic discharge, the product may malfunction. In this case, please remove the batteries and wait 5 minutes and then replace the batteries.



3 Set Your Target

Where does your path lead? A hidden dinosaur? Another explorer? A secret message? You decide. Then, set your target in place! You can also create a path to re-trace your way back to home base.



KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE — DO NOT DISCARD Questions? Visit unclemilton.com



MANUFACTURED BY UNCLE MILTON INDUSTRIES, INC. P.O. Box 6281
THOUSAND OAKS, CA 91359 USA
©2014 UMI. All rights reserved. ® and TM designate trademarks of Uncle Milton Industries, Inc.
MADE IN CHINA