



EXPEDITION SHOE LIGHTS

ACTIVITY GUIDE WITH INSTRUCTIONS


My Fellow Explorer,

As night falls, lighting a safe path on wooded trails or on the way back to home base is vital. Your new Expedition Shoe Lights are a valuable asset, allowing you to light the way without a flashlight, keeping your hands free for other important tasks.

Start exploring with the activities described below, or use your imagination to think of your very own games and adventures!


IMPORTANT! Shoe Lights are not waterproof. So don't get them wet!

Dual mode
on/off
switch



Secure to
shoes by
inserting
shoe strap
or laces
here.

Adjust the
lights
angle for
best path
illumination



Laces can
also tie
across built-
in clip

REPLACING BATTERIES

Tool required – small Phillips-head screw driver 

1. Using a Phillips-head screwdriver, remove the battery compartment cover.
2. Install 2 fresh LR44/AG13 button cell batteries only. Make sure the "+" and "-" ends are inserted correctly, as indicated in the battery compartment.
3. Replace the battery compartment cover. Do not over-tighten screw.



NIGHT CRITTER HUNT

Find out what critters are crawling around your backyard at night! Fasten on and illuminate your Shoe Lights, then, with a parent, slowly walk through your yard at night. Carefully observe the ground and see what creatures come out to greet you! Keep a record of what you see.

BATTERY SAFETY INFORMATION

- Non-rechargeable batteries are not to be recharged
- Rechargeable batteries are to be removed from the toy before being charged
- Rechargeable batteries are only to be charged under adult supervision
- Different types of batteries or new and used batteries are not to be mixed
- Batteries are to be inserted with the correct polarity
- Exhausted batteries are to be removed from the toy
- The supply terminals are not to be short-circuited
- Do not mix old and new batteries
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries
- Do not dispose of batteries in fire. Battery may explode or leak.

RED VERSUS WHITE!

This outdoor, nighttime game turns you and a friend into the playing pieces! Ask a parent to prepare 11 fun questions about nature and science. Attach one Shoe Light to your shoe and one to a friend's. Turn them on and adjust them so one light glows white and the other red. Head outside and have your parent ask the prepared questions. Whoever answers correctly takes a step forward and scores a point. After all the questions are asked, the player with the most points wins!



National Geographic's net proceeds support vital exploration, conservation, research, and education programs.



JOIN THE ACADEMY
NatGeoAcademy.com



Parents: Experience the National Geographic Channel. Call your cable or satellite provider for availability.

Visit our website:

kids.nationalgeographic.com

© 2011 National Geographic Society

NATIONAL GEOGRAPHIC and Yellow Border Design are trademarks of National Geographic Society. All rights reserved.



KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE — DO NOT DISCARD

Questions? Visit unclemilton.com

MANUFACTURED BY UNCLE MILTON INDUSTRIES, INC.
P.O. Box 6281
THOUSAND OAKS, CA 91359, U.S.A.
©2011 UMI. All rights reserved. ® and ® designate trademarks of Uncle Milton Industries, Inc.
PRINTED IN CHINA

16019-0250-1111-V01