
Installing batteries into tarantula

Tool required - Small Phillips head screwdriver

- 1. Using a Phillips head screwdriver remove the battery cover from the bottom of the tarantula (See Fig. 1).
- 2. Insert 2 "AAA" batteries and replace cover.




BATTERY SAFETY INFORMATION

- Batteries must be replaced by an adult.
- Follow the polarity (+/-) diagram in the battery compartment.
- Promptly remove dead batteries from the toy.
- Dispose of used batteries properly.
- Remove batteries for prolonged storage.
- Only batteries of same or equivalent type as recommended are to be used.
- DO NOT incinerate used batteries.
- DO NOT dispose of batteries in fire, as batteries may explode or leak.
- DO NOT mix old and new batteries or types of batteries (i.e., alkaline/standard).
- DO NOT use rechargeable batteries.
- DO NOT recharge nonrechargeable batteries.
- DO NOT short-circuit the supply terminals.

Install batteries into controller


- Using a Phillips head screwdriver remove the battery cover from the back of the controller (See Fig. 2).
- Insert 2 "AA" batteries and replace cover.



Using your R/C Tarantula

- Turn the power switches to the "ON" position on both the controller and tarantula (See Fig. 1).
- Move the tarantula forward or make it turn using the buttons on the controller (See Fig. 3).

Note: For best performance use your r/c tarantula on a smooth flat surface like a hardwood floor.



NOTE: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- \bullet Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- · Consult the dealer or an experienced radio/TV technician for help.

FCC ID: N9B2027UMI2006 or S362027UMI2007

49Mhz

MADE IN CHINA

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions.

(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including

interference that may cause undesired operation.

AWARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE - DO NOT DISCARD

Problems? Before taking this product back to the store, please call us. We can help! 1-888-742-2484 or go to www.unclemilton.com