



Millennium Falcon™ UV Light Laser


## **PRODUCT SET-UP**

Install batteries




Attach the Millennium Falcon onto the handle





#### **USING THE UV LASER**




Lower Button = Broad UV light


Upper Button = Pinpoint Laser Blasts

#### **CREATE A BATTLE SCENE**


1 Peel and stick the UV screen onto a wall. Hold the battle scene film onto the UV screen. Press and brush your fingers side-to-side onto the scene until it clings to the screen.



2 Illuminate and charge the scene by pressing the lower button to release broad UV light while moving the light around



**3** Quickly peel away the film from the UV screen to reveal your glowing battle scene




**4** Aim and press the upper button to shoot pinpoint laser blasts at the glowing ships. See how many you can hit before the scene fades away.





#### **SET-UP GLOW-IN-THE DARK TARGETS**

Peel and apply the ship decals onto smooth, clean surfaces anywhere in your room. Then, turn off the lights and shoot pinpoint lasers at the glowing targets.



For best results apply the UV screen/decals onto smooth, clean surfaces. The screen/decals may not stick to heavily textured surfaces. Do not apply to fresh paint or wallpaper. Let the new paint/wallpaper dry for at least 3 weeks. Before applying the screen/decals to wallpaper or other delicate surfaces, test in an inconspicuous area. Keep the decals away from cribs and out of reach of young children to prevent choking hazard.

### **CREATE LIGHT DRAWINGS**

Be creative! Think of ways to create your favorite Star Wars characters, vehicles and more.









generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:





Use different objects and broad UV light to make silhouettes of different shapes.

Use the pinpoint laser to draw details onto your image.

BATTERY SAFETY INFORMATION

- Only adults should install and replace batteries.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Different types of batteries or new and used batteries are not to be mixed.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.

· Do not mix old and new batteries.

- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- Do not dispose of batteries in fire. Battery may explode or leak.
- Batteries should be recycled or disposed of as per state and local quidelines.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment

- Reorient or relocate the receiving antenna.
   Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

Conforms to safety requirements of ASTM F963

IMPORTANT: In an environment with electrostatic discharge, the product may malfunction. In this case, please remove the batteries and wait 5 minutes and then replace the batteries.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.



Not for children under 3 years.

This product and its batteries must be disposed of separately at your local waste recycling centre. Do not dispose them in your household waste bin.

# KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE DO NOT DISCARD

Questions? Visit unclemilton.com







©\* and TM\* designate U.S. trademarks of Uncle Milton Industries, Inc. P.O. Box 6281 Thousand Oaks, CA 91359 USA. Printed in China. Product and colors may vary.

© 2015 UMI. All rights reserved.

© & ™ Lucasfilm Ltd. All rights reserved.

15202-0250-0615-V01