

AAA/LR03 x2 Batteries not included
Requires 2 x 1.5V AAA/LR03 batteries

AA/LR6 x4 Batteries not included
Requires 4 x 1.5V AA/LR6 batteries

Planet Set-up

Remove each of the Rover name stickers and apply below the pinpoint of light that shows that Rover's landing spot.





Lander/Rover Name: Viking 2
Landing Date: September 3, 1976
Purpose of Mission: Mapping the planet's surface.




Lander/Rover Name: Curiosity
Landing Date: August 5, 2012
Purpose of Mission: To discover if Mars could ever support life forms like microbes.



Lander/Rover Name: Mars 3
Landing Date: December 2, 1971
Purpose of Mission: To study the atmospheric composition and measure mechanical and chemical properties of the surface.



Lander/Rover Name: Spirit
Landing Date: January 3, 2004
Purpose of Mission: Geological research to characterize rocks and soils that may hold clues to past water activity.



Battery Installation

Tool required - Small Phillips head screwdriver
Requires 4 "AA" alkaline batteries (not included).
Requires 2 "AAA" alkaline batteries (not included).

Wall Mount

1. Using a Phillips head screwdriver, remove the battery cover as shown.
2. Insert 4 "AA" batteries as indicated in the battery compartment and replace cover.
3. IMPORTANT! Switch Mars in My Room to the ON position before handing on the wall.


PLEASE NOTE: The unit will not activate without the remote control.

Wall Installation

Note: Product is only intended to mount on a vertical wall.

Remote Control

1. Using a Phillips head screwdriver, remove the battery cover as shown.
2. Insert 2 "AAA" batteries as indicated in the battery compartment and replace cover.



Operation

IMPORTANT: The ON/OFF switch located on the back of the Mars In My Room must be switched to the ON position.

On/Off
button



NOTE: For best Mars illumination, use in a darkened room.

On/Off

To turn the Mars on, press the ON/OFF button on your remote. Press ON/OFF button again to turn off.

Auto Off

Mars automatically shuts off after approximately 30 minutes if there is no manual interaction.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

BATTERY SAFETY INFORMATION

- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Different types of batteries or new and used batteries are not to be mixed.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- Do not dispose of batteries in fire. Battery may explode or leak.

**KEEP THESE
INSTRUCTIONS
FOR FUTURE
REFERENCE —
DO NOT DISCARD**

Questions?
Visit
unclemilton.com



MANUFACTURED BY UNCLE MILTON INDUSTRIES, INC.
P.O. Box 6281
THOUSAND OAKS, CA 91359 USA
©2013 UMI. All rights reserved. ® and TM designate
trademarks of Uncle Milton Industries, Inc.
MADE IN CHINA